



Headphone Adapter Accessory

(An accessory that enables headphones with a 1/4" plug to be used with the ACE Apex metal detector.)



Contents: Headphone adapter cable and clip

Installation Procedure:



1. Remove screw and metal clip beneath detector stand.



2. Insert screw into metal and plastic clip as shown.



3. Install clips onto bottom of detector stand.



4. Insert headphone adapter into plastic clip.



5. Plug adapter into 1/8" headphone jack on back of control box.



6. Headphone adapter installed

GARRETT[®]

METAL DETECTORS

1526600 REV. A.0920 • © 2020 Garrett Electronics, Inc.

